LUUM

General Care + Maintenance

- Clean stains and spots promptly
- · Always test the cleaning agent in an inconspicuous area of the fabric first
- · Do not over saturate with liquid
- Follow cleaning product instructions
- · Vacuum regularly with a proper upholstery attachment

Cleaning Codes

- W Clean with a water-based cleaning agent. Do not use solvent products.
- S Clean with a dry cleaning or solvent-based cleaning agent. Do not use water-based cleaning products.
- WS Clean with either a water-based or solvent-based cleaning agent.

Care for Decoy Vinyl

Decoy is a high-performance phthalate-free vinyl upholstery fabric that has been tested using the following cleaners resulting in no visible changes to color:

Cleaner/Disinfectant	Result
Accel Prevention Concentrate	Slight Effect
Accel TB	Slight Effect
Asepticare TB-II	Severe Effect
Birex SE Disinfectant	Slight Effect
BLEACH-RITE Disinfecting Spray	Not Tested
Cavicide	Severe Effect
Caviwipes	Slight Effect
Citrace Germicide	Slight Effect
Clorox Broad Spectrum	Severe Effect
Clorox Disinfecting Wipes	No Effect
Clorox EZ Kill Wipes	Slight Effect
Clorox Healthcare Bleach Germicidal Wipes	Slight Effect
Clorox Healthcare Hydrogen Peroxide Wipes	Slight Effect
Clorox Hydrogen Peroxide Disinfectant	No Effect
Diluted Bleach, 10:1 Ratio	No Effect
Fade-A-Dyne II	Slight Effect
Fantastik Spray Cleaner	Slight Effect
Formula 409 All Purpose Spray Cleaner	Slight Effect
Greenworks All Purpose Cleaner	No Effect
HealthLink EZ Kill Wipes	Slight Effect

LUUM

Care for Decoy Vinyl (continued)

Cleaner/Disinfectant	Result
Isopropyl Alcohol	No Effect
Lysol Foaming Disinfectant Cleaner	Slight Effect
Lysol Spray	Slight Effect
Neutral Disinfectant Cleaner	No Effect
Oasis 146	No Effect
Oasis Quat 144	No Effect
Optim 33TB	Slight Effect
Oxivir TB	Slight Effect
Oxycide	Slight Effect
Perisept	No Effect
Purell Food Service Sanitizer	No Effect
Precise Spray	Severe Effect
Sani-Cloth HB	No Effect
Sani-Cloth Plus	Severe Effect
Sani-Professional Multi-Surface Wipes	Slight Effect
Sani-Professional Table Turners	No Effect
SaniZide Plus Germicidal Solutions	Slight Effect
Simple Green	Slight Effect
Solid Sense Wipes	No Effect
Super Sani-Cloth	Slight Effect
Super Sani-Cloth AF3	Slight Effect
Super Sani-Cloth with Bleach	Severe Effect
Virex II 256	No Effect
Virox 5	Slight Effect
Virox AHP 5 Disinfectant Cleaner Surface Wipes	Slight Effect
Wex-Cide 128	Severe Effect

No Effect No change in color or surface finish.

Slight Effect A change in color or surface finish only visible at certain angles.

Moderate Effect A change in color or surface finish visible from all angles and directions, but does

not appreciably alter the original condition of the material.

Severe Effect A change in color or surface finish, which obviously and markedly alters the

original condition of the material.

The above evaluations are indicators after laboratory testing performed with proper cleaner/disinfectant usage. After each application, the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue. Improper use of cleaners/disinfectants can expedite a product failure and void warranty.

Canada 877.705.LUUM luumtextiles.ca **USA** 877.705.LUUM luumtextiles.com International 919.464.2922 luumtextiles.com