

LUUM

General Care + Maintenance

- Clean stains and spots promptly
- Always test the cleaning agent in an inconspicuous area of the fabric first
- Do not over saturate with liquid
- Follow cleaning product instructions
- Vacuum regularly with a proper upholstery attachment

Cleaning Codes

- W** Clean with a water-based cleaning agent. Do not use solvent products.
- S** Clean with a dry cleaning or solvent-based cleaning agent. Do not use water-based cleaning products.
- WS** Clean with either a water-based or solvent-based cleaning agent.

Care for Welded

Welded is a woven fabric protected with a clear Tekloom TPE layer (or thermoplastic elastomer). Welded has been tested using the following cleaners resulting in no visible changes to color:

Cleaner/Disinfectant	Result
3M C Diff Solution Tablets	No Effect
3M Neutral Quat Disinfectant Cleaner Concentrate 23H	No Effect
3M Neutral Quat Disinfectant Cleaner Concentrate 23L	No Effect
3M HB Quat Disinfectant 25L	No Effect
Amphyl	No Effect
CariCide	No Effect
CaviWipes XL	No Effect
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes	No Effect
Ecolab A456 II	No Effect
Ecolab Neutral Disinfectant Cleaner	No Effect
Formula 409	No Effect
Hydrogen Peroxide	No Effect
Lysol Disinfectant Spray	No Effect
Oxivir 1	No Effect
Oxivir 5 16	No Effect
Oxivir Plus	No Effect
Oxivir Tb Wipes	No Effect
Oxycide	No Effect

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

**Care for Welded
(continued)**

Cleaner/Disinfectant	Result
Perisept	No Effect
Sani-Cloth AF3 Germicidal Disposable Wipes	No Effect
Steris (Coverage Spray HB Plus)	No Effect
Stride Fragrance Free SC Neutral Cleaner	No Effect
Virex 256	No Effect
VIrex Plus	No Effect
Wexcide 128	No Effect

The above evaluations are indicators after laboratory testing performed with proper cleaner/disinfectant usage. After each application, the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue. Improper use of cleaners/disinfectants can expedite a product failure and void warranty.

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.