

LUUM

General Care + Maintenance

- Clean stains and spots promptly
- Always test the cleaning agent in an inconspicuous area of the fabric first
- Do not over saturate with liquid
- Follow cleaning product instructions
- Vacuum regularly with a proper upholstery attachment

Cleaning Codes

W Clean with a water-based cleaning agent. Do not use solvent products.

S Clean with a dry cleaning or solvent-based cleaning agent. Do not use water-based cleaning products.

WS Clean with either a water-based or solvent-based cleaning agent.

Care for High Performance

Polyurethane Upholstery:

Meta Texture

Monotex

Perilune

Synaptic

These fabrics feature Cleangene technology. Cleangene is a stain inhibiting polymer inherent to the material make-up. Unlike topical treatments it does not wear off. These fabrics have been tested using the following cleaners:

Cleaner/Disinfectant	Result
Accel Prevention Concentrate	No Effect
Accel TB	No Effect
Asepticare TB-II (Ecolab)	Severe Effect
Birex SE Disinfectant (Biotrol)	Slight Effect
BLEACH-RITE Disinfecting Spray (Current Technologies)	Not Tested
Cavicide (Metrex)	Severe Effect
Caviwipes (Metrex)	Slight Effect
Citrace Germicide (Clorox Company)	Slight Effect
Clorox Broad Spectrum (Clorox)	Severe Effect
Clorox Disinfecting Wipes (Clorox)	Slight Effect
Clorox EZ Kill Wipes (Clorox Company)	Slight Effect
Clorox Healthcare Bleach Germicidal Wipes (Clorox)	Slight Effect
Clorox Healthcare Hydrogen Peroxide Wipes (Clorox)	Slight Effect
Clorox Hydrogen Peroxide Disinfectant (Clorox)	No Effect
Diluted Bleach, 10:1 Ratio (Clorox Company)	No Effect
Fade-A-Dyne II (Russ Medical Specialties)	Slight Effect
Fantastik Spray Cleaner (S.C. Johnson & Son)	Slight Effect
Formula 409 All Purpose Spray Cleaner (Clorox Company)	Slight Effect
Greenworks All Purpose Cleaner (Clorox)	No Effect
HealthLink EZ Kill Wipes (Health Link)	Slight Effect
Isopropyl Alcohol (Miscellaneous)	No Effect
Lysol Foaming Disinfectant Cleaner (Brand, IC)	Slight Effect
Lysol Spray (Brand, IC)	Slight Effect

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.

LUUM

**Care for High Performance
Polyurethane Upholstery
(continued)**

Cleaner/Disinfectant	Result
Neutral Disinfectant Cleaner (Ecolab)	No Effect
Oasis 146 (Ecolab)	Not Tested
Oasis Quat 144 (Ecolab)	Slight Effect
Optim 33TB (Virox Technologies)	Slight Effect
Oxivir TB (Diversey Inc.)	No Effect
Oxycide (Ecolab)	Slight Effect
Perisept	No Effect
Purell Food Service Sanitizer	No Effect
Precise Spray (Caltech Industries)	Severe Effect
Sani-Cloth HB (PDI)	No Effect
Sani-Cloth Plus (PDI)	Severe Effect
Sani-Professional Multi-Surface Wipes (PDI)	Slight Effect
Sani-Professional Table Turners (PDI)	Slight Effect
SaniZide Plus Germicidal Solutions (Safetec of America)	Slight Effect
Simple Green (Sunshine Makers, Inc)	Slight Effect
Solid Sense Wipes (KAY)	Slight Effect
Super Sani-Cloth (PDI)	Slight Effect
Super Sani-Cloth AF3 (PDI)	Slight Effect
Super Sani-Cloth with Bleach (PDI)	Severe Effect
Virex II 256 (Diversey Inc.)	No Effect
Virox 5 (Diversey, Inc)	Not Tested
Virox AHP 5 Disinfectant Cleaner Surface Wipes (Diversey, Inc.)	Slight Effect
Wex-Cide 128 (Wexford Labs)	Severe Effect

**Care for High Performance
Polyurethane Upholstery:
Touch Tone**

Cleaner/Disinfectant	Result
Bleach: Water (1:10)	Slight Effect
3M C DIFF Solution Tablets	No Effect
Cavicide	No Effect
Ecolab A456 II	No Effect
Formula 409	No Effect
Hydrogen Peroxide	No Effect
Isopropyl Alcohol (70%)	No Effect
Lysol Disinfectant Spray	No Effect
Oxivir Five 16	No Effect
Perisept	No Effect
Sani Cloth AF3 Wipes	No Effect
Virex Plus	No Effect

LUUM

No Effect	No change in color or surface finish.
Slight Effect	A change in color or surface finish only visible at certain angles.
Moderate Effect	A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material.
Severe Effect	A change in color or surface finish, which obviously and markedly alters the original condition of the material.

The above evaluations are indicators after laboratory testing performed with proper cleaner/disinfectant usage. After each application, the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue. Improper use of cleaners/disinfectants can expedite a product failure and void warranty.

Canada
877.705.LUUM
luumtextiles.ca

USA
877.705.LUUM
luumtextiles.com

International
919.464.2922
luumtextiles.com

Visit the Luum website for additional information including warranty, terms & conditions and ordering information. For textiles inquiries, please contact Luum customer service.